

Instruction for Use

021414/08/06

Wind Direction Transmitter „First Class“

4.3150.x0.012 / 110 / 212



ADOLF THIES GmbH & Co. KG

Hauptstraße 76

Box 3536 + 3541

Phone ++551 79001-0

www.thiesclima.com

37083 Göttingen Germany

37025 Göttingen

Fax ++551 79001-65

info@thiesclima.com

Contents

1	Models available	2
2	Application	3
3	Mode of Operation	3
4	Recommendation Site Selection / Standard Installation	4
5	Installation.....	4
5.1	Mounting of the Wind Vane	4
5.2	Electrical Mounting	5
5.3	Mechanical Mounting	5
5.4	North Alignment.....	6
6	Plug mounting	6
7	Maintenance	7
8	Connecting Diagram	7
9	Technical Data.....	10
10	Dimensional drawing	12
11	Accessories	13

Figures

Figure 1: Mounting of the wind vane	5
---	---

1 Models available

Order- No.	Meas. range	Elect. Output	Potentiometer-protective circuit	Power Supply	Heating
4.3150.00.110	0...360°	Potentiometer: 10 kΩ Series resistance : 50 Ω	yes	4...42 V DC current: $\leq U_s / 10 \text{ k}\Omega$	yes
4.3150.10.110	0...360°	Potentiometer: 10 kΩ Series resistance: 50 Ω	yes	4...42 V DC current: $\leq U_s / 10 \text{ k}\Omega$	no
4.3150.00.012	0...360°	Potentiometer: 2 kΩ Series resistance: 50 Ω	yes	4...42 V DC current: $\leq U_s / 2 \text{ k}\Omega$	yes
4.3150.00.212	0...360°	Potentiometer: 2 kΩ	no	0...30 V DC current: $\leq U_s / 2 \text{ k}\Omega$	yes
4.3150.10.212	0...360°	Potentiometer: 2 kΩ	no	0...30 V DC current: $\leq U_s / 2 \text{ k}\Omega$	no

2 Application

The wind direction transmitter serves for the detection of the horizontal wind direction in the field of meteorology and the technology of environmental protection.

Special characteristics:

- High level of measuring accuracy and resolution
- High damping ratio at a small delay distance
- Low starting threshold
- Magnetic coupling, which is free of hysteresis and wear, situated between the axis of vane and potentiometer.
- Electronic protective circuit for the limiting of current, and against erroneous connection, with model 4.3150.x0.110 und 4.3150.x0.012
- Easy removal, and mounting when changing the ball bearing

Optional, an electronically-regulated heating system has been installed for winter time use of the wind direction transmitter (see chapter 1, “models available”), in order to prevent the ball-bearing and the external rotation parts from freezing. Power for the heating system could be provided for instance by our Power Supply Unit, order-no. 9.3388.00.000.

Remark:

When using fastening adapters (angle, traverses, etc.) please take a possible effect on the measurements by turbulences into consideration.

3 Mode of Operation

The dynamic characteristics of the wind vane is achieved by the aluminum light-weight construction. The co-action of wind vane and balance weight results in a high damping ratio with small delay distance as excellent characteristic of the complete vane.

The axis of the wind vane is running in ball bearings, and is coupled, in contact less magnetic manner, with the axis of the integrated potentiometer. Thus, clearance and friction in the coupling are avoided, and an easy starting is guaranteed.

An AC- or DC-voltage of 24 V is intended for the separate supply of the optional heating. In all probability, the heating guarantees a trouble-free function of the Wind Direction Transmitter First Class even under extreme meteorological icing-conditions..

The outer parts of the instrument are made of corrosion-resistant anodized aluminum, and stainless steel. Highly effective labyrinth gaskets and O-rings protect the sensitive parts inside the instrument against humidity and dust.

4 Recommendation Site Selection / Standard Installation

In general wind measurement instruments should be able to detect the wind conditions of a large area. In order to obtain comparable values when determining the surface wind, measurements should be taken at a height of 10 meters over an even area with no obstacles. An area with no obstacles means that the distance between the wind direction transmitter and an obstacle should be at least 10 times the height of the obstacle (s. VDI 3786 Part 2). If it is not possible to fulfill this condition then the wind direction transmitter should be set up a height where local obstacles do not influence the measured values to any significant extent (approx. 6-10 m above the obstacle). The wind direction transmitter should be set up in the center of flat roofs and not on the edge in order to avoid any preferential directions.

5 Installation

5.1 Mounting of the Wind Vane

Before the wind direction transmitter can be installed at a selected site, the wind vane and the balance weight must be mounted at the adaptors of the wind direction transmitter. The individual process steps are explained in the following list, and by the drawing (figure 1). Necessary tool: Philips screw driver.

- **Wind vane:**
 - Remove the screw M3 from the thin adaptor.
 - Put the wind vane onto the thin adaptor. (The longer part of the wind vane deflector must indicate upward).
 - Put the screw M 3 through the hole of the wind vane from below into the adaptor, and screw tight.
- **Balance weight:**
 - Remove the screw M3 from the thicker adaptor.
 - Put the balance weight onto the thicker adaptor.
 - Put the screw M 3 through the hole of the balance weight from below into the adaptor, and screw tight.

Remark:

As the screws are covered with locking varnish they are rough-running with the fastening.

The screw head must be immersed completely in the counter-bore of balance weight and wind vane!




Figure 1: Mounting of the wind vane

5.2 Electrical Mounting

Solder a shielded cable with diameter 7-8 mm and a core cross-section of 0,5...0,75 mm² to the enclosed coupling socket.

- The number of necessary wires is given in the connection diagram (chapter 8).

Cable recommendation	
Type/ No. of cores /Diameter	Cable diameter
LIYCY 4 x 0,75 mm ²	ca. 7 mm
LIYCY 5 x 0,50 mm ²	ca. 7 mm
LIYCY 6 x 0,75 mm ²	ca. 7,7 mm
LIYCY 7 x 0,50 mm ²	ca. 7,5 mm
LIYCY 8 x 0,50 mm ²	ca. 8 mm

5.3 Mechanical Mounting

Mount the transmitter onto a pipe socket of R 1" (Ø 33,5 mm) and a length of 25 mm. The pipe socket must have an internal diameter of at least 25 mm as the wind direction transmitter must be connected electrically with a plug from below. After electrical connection the wind direction transmitter is put onto the pipe socket, and is fixed by means of 2 threaded pins (female hexagon 3 mm) at the base of the transmitter.

Attention:

Storing, mounting and operation under weather conditions is permissible only in vertical position, as otherwise water can get into the instrument.


5.4 North Alignment

Remark:



When the wind direction transmitter is in operation, the north marking (line mark) at the base of the transmitter must indicate to the geographical north.

6 Plug mounting

Coupling socket 507550 (Binder, Serial 423), EMC with cable clamp



1. Stringing parts on cable acc. to plan given above.
 2. Stripping cable sheath 20 mm
Cutting uncovered shield 15 mm
Stripping wire 5mm.
- Cable mounting 1*
Putting shrink hose or insulating tape between wire and shield.
- Cable mounting 2*
If cable diameter permits, put the shield backward on the cable sheath.
3. Soldering wire to the insert, positioning shield in cable clamp.
 4. Screwing-on cable clamp.
 5. Assembling remaining parts acc. to upper plan.
 6. Tightening pull-relief of cable by screw-wrench (SW16 und 17).



7 Maintenance

If properly installed, the instrument requires no maintenance. Heavy pollution can lead to blockage of the slot between the rotating and the stable parts of the transmitter. Thus it is advisable to remove the accumulated dirt from the instrument .

Certain symptoms of wear and tear can appear on the ball bearings after years of use. These symptoms are expressed in a lowered sensitivity of response, standstill or run-noises of the ball bearings. In case that such disturbances might occur we recommend to return the instrument - in original package – to the factory for maintenance work.

8 Connecting Diagram


Remark

Models 4.3150.x0.110 / 012 are equipped with electronic protective circuit for current limitation and against erroneous connection.


Attention: Model 4.3150.x0.212

When the wind vane rotates over the north point (0 / 360°) the potentiometer slider connects beginning and end of the potentiometer. Therefore, the supply voltage of the potentiometer must show a current limitation of max. 20 mA. When using power supply units temporary current peaks with the power control might lead to damages. Therefore, an additional protective resistance is strongly recommended .

Order – No.
 4.3150.00.110
 4.3150.10.110*
 4.3150.00.012




View on the
 soldered joint
 of the counter
 plug




- *Order-No 4.3150.10.xxx (without heating) contact 7 and 8 is not connected
- With electronic protective circuit for current limitation and against erroneous connection (see Technical Data)

Order – Nr,	Contact	Name	Function
4.3150.00.110 4.3150.10.110* 4.3150.00.012	1	SIG	Signal (Pot wiper)
	2	GND	Ground
	3	+Us	Supply 4 V...42 V DC
	4	AGND	Analogue ground
	5	NC	Not connected
	6	NC	Not connected
	7	HZ	Heating supply: Voltage: 24 V AC/DC Power: 25 W
	8		
*Order-No 4.3150.10.xxx (without heating) contact 7 and 8 is not connected			

Order – No.
4.3150.00.212
4.3150.10.212*



View on the
soldered joint
of the counter
plug



- *Order-No 4.3150.10.xxx (without heating) contact 7 and 8 is not connected
- Without electronic protective circuit


Order – Nr,	Contact	Name	Function
4.3150.00.212 4.3150.10.212*	1	SIG	Signal (Pot wiper)
	2	GND	Ground
	3	+Us	Supply 0 V...30 V DC
	4	AGND	Analogue ground
	5	NC	Not connected
	6	NC	Not connected
	7	HZ	Heating supply: Voltage: 24 V AC/DC Power: 25 W
	8		
*Order-No 4.3150.10.xxx (without heating) contact 7 and 8 is not connected			

9 Technical Data

Characteristic	Description
Measuring Range	0 ... 360 °
Measuring Accuracy	0,25% (1°)
Survival speed	85 m/s up to 0,5 h (without damages)
Permissible ambient conditions for operation	-50 to +80°C all occurring situations of rel. humidity incl. dew moistening
Electrical output at 4.3150.x0.212	Potentiometer (see chapter 1, "models available")
Electrical output at 4.3150.x0.012 4.3150.x0.110	Potentiometer (see chapter 1, "models available") An electronic protective circuit avoids an overloading of the potentiometer in case of erroneous connection, and on transition from 0° to 360 °. The protective circuit represents a nominal series resistance of 50 Ω, however it limits the short-circuit-current on transition from 0° to 360 ° (and vice versa) to ≤ 1 mA at a 10 kΩ Pot and ≤ 2 mA at using a 2 kΩ Pot.
Linearity	0,25% (1°)
Starting threshold	< 0,5 m/s at 10° amplitude
Delay distance	< 1 m (acc. to ASTM D 53666 – 96)
Damping ratio	D > 0,25 (acc. to ASTM D 53666 – 96)
Quality factor	K > 1 $K = \frac{4 \cdot D \cdot \omega_0}{\rho \cdot u}$
	D damping ratio, ω ₀ angular frequency of undamped oscillation, ρ air density u wind speed
Heating	Surface temperature of housing neck > 0 °C at 20 m/s up to –10 °C air temperature, at 10 m/s up to –20 °C using the Thies icing standard 012002 on the housing neck heating regulated with temperature sensor

Electrical supply for Potentiometer at 4.3150.x0.212	Voltage U_s : 0V DC ... 30 V DC, Please maintain a supply current of max. 20mA – short circuit at the north point (galvanic isolation from the housing) Current: \leq supply voltage divided by potentiometer resistance
Electrical supply for Potentiometer at 4.3150.x0.012 4.3150.x0.110	Voltage U_s : 4V DC to 42 V DC (galvanic isolation from the housing) Current: \leq supply voltage divided through pot. resistance ≤ 1 mA at transition $0 \rightarrow 360^\circ$ und $360 \rightarrow 0^\circ$ equipped with 10 k Ω Potentiometer and ≤ 2 mA at transition $0 \rightarrow 360^\circ$ und $360 \rightarrow 0^\circ$ equipped with 2 k Ω Potentiometer serial resistance: 50 Ω (representative)
Electrical supply for heating	voltage: 24V AC/DC (galvanic isolation from the housing) Capacity: 25 W
Connection	8-pole plug connection for shielded cable in the shaft (see connecting diagram)
Montage	Mounting on mast 1", for ex. DIN 2441 1½ " with separate adaptor (option)
Dimensions	See dimensional drawing
Weight	ca. 0,7 kg
Protection	IP 55 (DIN 40050)
EMC	EN 61000-6-2:2001 (immunity) EN 55022:2001, Class B (interfering transmission)

10 Dimensional drawing



11 Accessories

The following accessories are available for the wind direction transmitter:

<p>Traverse 0,6 m For mounting the wind speed and wind direction transmitter jointly onto a mast</p>	<p>4.3174.00.000</p>	<p>Horizontal sensor distance: 0,6 m Vertical sensor distance: 0,2 m Mast receptacle: 48 - 50 mm Material: Aluminum, anodised Dimensions: tube Ø 34x4mm, 668 mm long, 756 mm high</p>
--	----------------------	---

<p>Hanger –FIRST CLASS- 1m For the lateral mounting of a wind speed and wind direction transmitter onto a mast..</p>	<p>4.3184.01.000</p>	<p>Sensor distance to mast: 1 m Mast clamp: 40 – 80 mm Tube diameter: 34 mm Material: Aluminum</p>
--	----------------------	--

<p>Lightning rod For mounting the a/m traverse or hanger.</p>	<p>4.3100.98.000</p>	<p>Dimension: Ø 12 mm, 500 mm long, 1050 mm high Material: Aluminum</p>
---	----------------------	---

Please contact us for other accessories such as cables, power supply units, masts, as well as for additional mast- or system-constructions.

Example: Wind transmitter with traverse and lightning rod.





ADOLF THIES GmbH & Co. KG

Hauptstraße 76 37083 Göttingen Germany
P.O. Box 3536 + 3541 37025 Göttingen
Phone ++551 79001-0 Fax ++551 79001-65
www.thiesclima.com info@thiesclima.com



- Alterations reserved -